

Second AnAqSim Tutorial

Building a multi-layer heterogeneous, anisotropic model with various boundary conditions

Contents

Introduction	2
Opening the First Tutorial Model.....	2
Adding New Domains for the Multi-Layer Area.....	2
Interdomain Line Boundary to Define the 3D Region.....	3
Putting the Well and River Reach into the New Domains	6
Spatially-Variable Area Sinks in 3D Region	6
SVAS by Domain.....	7
SVAS by Polygon	7
Well SVAS Basis Point Spacing	9
Solving the System of Equations.....	10
What to do if your model has too many equations (AnAqSimEDU users)	10
Making a Plot of the Solution	11
Plot Input Settings.....	11
Make a Plot of Entire Model Area with Head Contours and Vectors	11
Make Close-up Plots of 3D Area, Both Levels	12
Examining Head Differences Between Levels.....	14
Making a Plot with Pathlines	15
Analyzing the Solution in Detail	16
Examining Head at the Discharge-Specified Well.....	16
Checking River Reach Discharge	17
Making Profiles along a Line	18
Profiles Showing Head, Domain Boundaries, and Pathlines.....	18
Profiles Showing Domain Discharges.....	20
Profiles Showing Extraction, Evaluating SVAS Accuracy	21
Further Exploration for AnAqSim Users.....	23
Make the 3D area 4 levels	23
Add Head-Specified and/or Discharge-Specified Multi-Domain Wells.....	23
Wrap up and Next Steps	24

Introduction

This second tutorial builds on the model created in the first tutorial. The first tutorial model was two-dimensional and steady, but this second tutorial will guide you through creating a model that has a multi-layer three-dimensional (3D) region in an area near the middle reach of the river. The well will be changed from fully-penetrating to partially-penetrating. This model may be built with either AnAqSim or AnAqSimEDU, and will contain two levels in the multi-level region. More levels are possible with AnAqSim, and there is some instruction about that at the end of the tutorial.


Opening the First Tutorial Model

Either begin with the model you had after completing the first tutorial, or use the one named *tutor1.anaq* which was installed with the AnAqSim software. The folder with the tutorial input files is usually located in one of the following directories on your computer:

- Program Files/Fitts Geosolutions/AnAqSim/Documentation/tutor1.anaq (64-bit AnAqSim)
- Program Files (x86)/Fitts Geosolutions/AnAqSim/Documentation/ tutor1.anaq (32-bit AnAqSim or AnAqSimEDU)

Open the first tutorial model by selecting *File/Open* from the main menu, then locate and open the first tutorial model. Next select *File/Save As* and save this under another name such as “tutor2.anaq”.

Zoom in on the area where you will make the model multi-level (3D) so that the resulting view looks something like the following image. If you want to review [how to zoom and pan in the plot view, see this short video](#). In this case, the basemap (also available in the AnAqSim software *Documentation* directory) is displayed in gray. The model elements are displayed in green.



Adding New Domains for the Multi-Layer Area

In the area near the well and the middle river reach ($h=114$ to $h=108$), we will create a region with two levels instead of one. The first step is to create new domains for this region. Select *Model Input/Domains/Confined and/or Unconfined* to bring up the domains data table, which contains two domains “all” for most of the

model, and “recharge basin” for the recharge basin area. These two domains have the same properties, but differing recharge rates.

We will add 2 new domains for the multi-level region. The quickest way to create the new rows is to duplicate the two existing rows. Select both existing rows as is shown below.

Data: confined and/or unconfined domains

Label_unique	Level	Domain_Type	Top_elevation	Bottom_elevation	Average_head	Porosity	Storativity	Specific_yie
all	1	unconfined	110	82	110	0.11	0.001	0.1
recharge basin	1	unconfined	110	82	110	0.11	0.001	0.1

Then right-click and choose *Copy Selected Rows* and then right-click and select *Paste New Rows*. For a review of [how to edit input tables in the Data tab, please see this short video](#). Edit the first 5 columns of the new rows so they look like the following table. Columns 6+ will all be unchanged, since these domains all have the same properties, just different elevations.

Data: confined and/or unconfined domains

Label_unique	Level	Domain_Type	Top_elevation	Bottom_elevation	Average_head	Porosity	Storativity	Specific_yie
all	1	unconfined	110	82	110	0.11	0.001	0.1
recharge basin	1	unconfined	110	82	110	0.11	0.001	0.1
3D upper	1	unconfined	110	95	110	0.11	0.001	0.1
3D lower	2	confined	95	80	110	0.11	0.001	0.1

Note that the bottom elevation of the new two-level area is 80, a bit lower than the bottom elevation of the “all” domain at 82. This is just to show that elevations may change laterally in a model if you want them to. The “3D upper” domain is in level 1 and is unconfined with a base at elevation 95. The “3D lower” domain is in the 2nd level (level numbers increase with depth) and is confined with a constant saturated thickness of 15, going from elevation 80 to 95.


At this point, save your model with *File/Save* from the main menu or *Ctrl-C*.

Interdomain Line Boundary to Define the 3D Region

We have defined the two new domains that will apply in the 3D region, but still need to define the area where those domains exist. AnAqSim does this with external line boundaries that refer to the domains. In this case, we will create one new interdomain line boundary that will represent the lateral transition from the single-level “all” domain to the multi-level 3D area. At interdomain boundaries, the conditions imposed are continuity of flow and continuity of head across the boundary.

First, digitize the interdomain boundary. Select the *Plot* tab, and make sure that under the plot menu *Snap Settings/Snap to Elements* is checked. This allows the digitized interdomain line boundary to “snap to” the same vertex coordinates as the river line boundaries. When the cursor moves over an existing vertex, and orange box will appear; if you click with the orange box showing, it will snap to the same coordinates. Digitize a closed polygon boundary like the yellow one shown below, making sure to snap to the river vertexes labeled “h=114” and “h=108”. You can go around the boundary in either clockwise or counter-

clockwise order, but it is important to remember which way you went. To [review how to digitize, see this video](#).



Next, select *Model Input/Line Boundaries/Inter-Domain* and add a new row so it looks like this:

Data: inter-domain lines


Label	Domains_left	Domains_right	Parameters_per_line	Coordinates
ID	Select	Select	3	Edit
3D limits	Select	Select	3	Edit
	Select	Select		Edit

The “ID” boundary defined the limits of the recharge basin, and the new “3D limits” one will define the boundary of the 3D area. Click on the *Edit* button in the “3D limits” row and paste in the coordinates you just digitized, and then press *OK*.

Then, click on the *Select* button under *Domains_left*. If you digitized in clockwise order, select the “all” domain and if you digitized in counter-clockwise order, select both “3D upper” and “3D lower”. Imagine walking on the ground surface along the line you just digitized; *Domains_left* would be to your left as you walk along the boundary and *Domains_right* would be to your right. This interdomain boundary makes a transition from two levels (3D upper, 3D lower) on one side to a single level (all) on the other. By doing this, Interdomain boundaries can help you efficiently concentrate computing power and multiple levels in a limited area. Interdomain boundaries can also join a single domain on one side with a single domain on the other side.

Now click on the *Select* button under *Domains_right*. If you digitized in clockwise order, select both “3D upper” and “3D lower” and if you digitized in counter-clockwise order, select the “all” domain.

To check your input, select *Make Plot/Model Elements Only*, then select level 1 and press *OK*, and you should see something like this in the area near the well:




The new interdomain line boundary is now green, since it is composed of elements in the model. Move the cursor over the vertexes of the interdomain line boundary to check that the left/right sense of the domains is correct. Move the mouse across the boundary, and observe the domain listed at the left. When you are outside the 3D area, you should see this:

Domain Name:
all

When you are inside the 3D limits you should see this:

Domain Name:
3D upper

Now make a similar plot, but chose level 2 instead of level 1 and you will see something like this:



The river elements do not show up, since they are in level 1. Move the mouse across the boundary, and observe the domain listed at the left. When you are outside the 3D area, there is no level 2 and you should see a blank under *Domain Name*:

Domain Name:

When you are inside the 3D limits you should see this:

▲ Domain Name:
3D lower

Putting the Well and River Reach into the New Domains

The two domains that occupy the 3D area are “3D upper” and “3D lower”, but our input still lists the middle river reach and the well as being in domain “all”, which is no longer correct. We need to change the input for these elements and put them in the correct domains.

First, bring up the well data by moving the cursor near the well, right-clicking, and then selecting *Edit Nearest Well*. Then change the domain of the well from “all” to “3D lower”:

Data: discharge-specified wells

Label	Domain	X,Y	Radius	Discharge
W	3D lower	222.4071, -52.72507	0.3	-414

Now the well is screened only in the 3d lower domain from elevation 80 to 95, not in the “3D upper” domain above. In this manner, AnAqSim simulates partially-penetrating wells.

Second, edit the middle river reach by moving the cursor near this line boundary, right-clicking, and then selecting *Edit Nearest Line Boundary*. This will open the river line boundary table and highlight the middle reach row. Change the domain of the well from “all” to “3D lower”:

Data: river lines

Label	Domain	Parameters_per_line	Dries_up	Stage_start	Stage_end	Cond
lower	all	3	<input type="checkbox"/>	106	108	0.3
middle	3D upper	3	<input type="checkbox"/>	108	114	0.3
upper	all	3	<input type="checkbox"/>	114	121	0.3

The river now will be in the upper layer and there will be vertical resistance and 3D flow with the underlying 2nd level.

Save your model now, selecting *File/Save* from the main menu or *Ctrl-S*.

Spatially-Variable Area Sinks in 3D Region

In the 3D area there will be vertical leakage between the two levels. For each domain, this can be thought of as a distributed source/sink term like recharge, but it will vary with location. For example, near the well that is in “3D lower” there will be vertical leakage from “3D upper” to “3D lower” with leakage increasing closer to the well. To model this spatially-variable leakage, we need to use spatially-variable area sinks (SVAS). SVAS are required to simulate vertical leakage in multi-level areas of models, and also to simulate storage fluxes in transient models. In this steady model, SVAS are needed just in the 3D area where there is vertical leakage. Outside the 3D area, the model is single layer, steady, and the uniform recharge can still be modeled efficiently with a uniform area sink so there is no need to modify that input.

SVAS by Domain

SVAS can be input over the area spanned by a domain or the area spanned by a polygon. For this model, we will use both. First, we will enter an SVAS that applies over the 3D area. Select Model Input/Area Source/Sink/Spatially-Variable, Domain, and complete a row like this:


Data: spatially-variable area source/sink, by domain

Domain	Condition_Top	Top_flux_or_head	Top_surface	Condition_Bottom	Bottom_flux_or_head	Bottom_surface	Node_spacing
3D upper	Flux	0.0006	none	Flux	0	none	80

This SVAS applies to the area spanned by the “3D upper” domain. SVAS are applied for all levels of a model, including those that underlie and/or overly the specified domain. Since “3D upper” and “3D lower” span the same area, we only need to create an SVAS for one of these domains. The result would be the same if we chose either “3D upper” or “3D lower” as the *Domain*. *Condition_Top* is set to *Flux*, meaning that the sink/source rate into the top of the model is specified and equal to 0.0006, the same recharge rate that applies in the “all” domain outside the 3D area. *Condition_Bottom* is set to *Flux = 0*, so the bottom of the model (bottom of “3D lower”) is impermeable. The alternative top or bottom condition is *head_dependent_flux*, which is used for vertical leakage to a specified head at a surface water, for example.

Node_spacing is the approximate spacing between basis points in the SVAS. The leakage/storage fluxes are solved for perfectly at the basis points, and approximated with a smooth interpolated surface between basis points. AnAqSim will automatically populate the area of domain “3D upper” with basis points on a regular hexagonal grid of points, spaced about 80 units apart. To read more about SVAS, see papers by [Fitts \(2010\)](#) and [Strack and Jankovic \(1999\)](#).


To see how these basis points are distributed, select *Make Plot/Model Elements Only*, then select level 1 and press *OK*. You should see green “+” basis point symbols in the 3D area something like this:



A similar plot of level 2 would show basis points at these same locations. Move the cursor over some basis points to see the domain and top/bottom conditions at this point.

SVAS by Polygon

Where the rates of vertical leakage change over short horizontal distances, we need denser basis point spacing. We can use polygon SVAS and special well basis point spacing for this purpose. First, we will create a zone of denser basis points in the well/river vicinity using a polygon SVAS. Start by digitizing a polygon (either clockwise or counter-clockwise) that looks something like the yellow line in the following image. If you don't close the polygon, AnAqSim will close it for you from the first point to the last.



Then select *Model Input/Area Source/Sink/Spatially-Variable, Polygon* and edit the row so it looks like this:

Data: spatially-variable area source/sink, by polygon

Label	Nesting_level	Condition_Top	Top_flux_or_h	Top_surface	Condition_Botto	Bottom_flux_or_head	Bottom_surface	Node_spacing	Coordinates
close	1	Flux	0.0006	none	Flux	0	none	25	<input type="button" value="Edit"/>
									<input type="button" value="Edit"/>


Then click on the *Edit* button and paste in the coordinates of the polygon you just digitized. This will spread out basis points with a smaller spacing (25) inside the polygon. The domain basis points that were within this polygon will be automatically overwritten. The *Nesting_level* is used when you have multiple polygon SVAS that are nested within one another. Polygon SVAS with higher nesting levels overwrite polygon SVAS with lower nesting levels. We will input just one polygon SVAS, so nesting won't be an issue.

Save your input, and then select *Plot Input/What to Plot* and then check the *SVAS_polygons* box so that the SVAS polygons will be displayed in subsequent plots:

Data: what to plot

Window	Basemap	Basemap_File	Elements	Contours	Pathlines	Vectors	SVAS_polygons	AreaPathline_polygons	Calibration	Analysis_Inputs
	gray	Select	elements w/ details, control points	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Select *Make Plot/Model Elements Only* and choose level 1 to see the distribution of basis points and the SVAS polygon (light blue):




Well SVAS Basis Point Spacing

Vertical leakage rates change especially rapidly near a partially-penetrating well, so AnAqSim has a built-in means of creating basis point spacing that gets denser and denser close to a well. See the User Guide (*Help*) to read more about how this works. Select *Model Input/Area Source/Sink/Spatially-Variable, Well Basis Points* and create a row like this:


Data: basis point spacings near wells

Well_Labels	Max_node_spacing	Points_per_circle
Select	25	6
Select		


Then click the Select button and select the one well in the model:



This will create concentric circles of basis points, 6 per circle, with smaller and smaller circles until the innermost one which is just outside the well radius. The largest circle will be drawn such that the spacing between points is no more than *Max_node_spacing*. Generally set *Max_node_spacing* to a value close to the ambient domain or polygon basis point spacing. Switch to the *Plot* tab, zoom in on the 3D area, and then right-click and select *Set Plot Window to Current View*, which will make subsequent plots in this smaller area. Now select *Make Plot/Model Elements Only* and choose level 1 to create a plot like this:



Zoom in on the well to see the special well basis point placement more clearly:



At this point, save your model.

Solving the System of Equations

Most of the elements in the model have unknown strengths that will be solved for by building a system of boundary condition equations based on conditions at line boundary control points, SVAS basis points, etc. All this happens when you select *Solve* on the main menu. This will initiate the solve process, switch the view to the *Log* tab and print out information as the system is solved. For my version of this model, here is what was written to the log:

```

Log C:\Users\CFITTS\Documents\AnAqSim\Manual\tutor2EDU.anaq saved
Start solving system 8/19/2016 8:41:39 AM
439 equations and unknowns in system
Iteration 1 2 3 4 5
Converged within the specified solution check values.
Solve complete 8/19/2016 8:41:40 AM
  
```

The system had 439 equations and 439 unknowns. It took 5 iterations and about 1 second to solve within the convergence criteria listed under *Model Input/Solution/Check Settings*. Some of the equations in the model were nonlinear (vertical leakage equations at basis points, river equations) due to the nonlinear nature of the head-potential relationship in unconfined domains. Solving nonlinear equations requires iteration using updated linear approximations at each iteration.

What to do if your model has too many equations (AnAqSimEDU users)

AnAqSimEDU is limited to no more than 500 equations, and depending how you digitized your SVAS polygon, you may have exceeded this limit. If this was the case, AnAqSim gave you an error message telling you to simplify your model and reduce the number of equations. Here are some ways that you can simplify and reduce the number of equations:

- Graphically edit the SVAS polygon boundary, making it cover a smaller area (see this [video on how to graphically edit well and line boundary coordinates](#)).
- Increase the basis point spacing for the domain SVAS and/or the polygon SVAS.
- Decrease the parameters per line for the line boundaries, particularly the interdomain boundaries, which generate more equations per segment than other types of line boundaries.

Use one or more of the above strategies, and then press *Solve*. Repeat until the model is within the 500 equation limit and solves successfully.

Making a Plot of the Solution

Once the model is solved, AnAqSim offers many ways of examining the solution. The first to explore is a plan-view plot that shows head contours and velocity vectors. Before making the plot, we will adjust some of the plot input.

Plot Input Settings

Select *Plot Input/What to Plot* and check the boxes so they are like this:

Data: what to plot										
Window	Basemap	Basemap_File	Elements	Contours	Pathlines	Vectors	SVAS_polygons	AreaPathline_polygons	Calibration	Analysis_Inputs
	gray	Select	elements w/ details, control points	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Leaving the *Window* cell blank makes the plot cover the entire extent of the model. We will make a plot that shows the checked items.

Next select *Plot Input/Contour Settings* and adjust it like this:

Data: contour settings					
Surface	Subtract	Points_Evaluated	Increment	Minimum	Maximum
h	no	20000	0.5		


The blank cells for *Minimum* and *Maximum* mean that the minimum and maximum contours will be determined such that they cover the full range of head (h) in the plot area. Select *Plot Input/Vector Settings* and adjust to look like this:

Data: vector settings		
Vector_Type	Points_Evaluated	Scale_Factor
v	600	1

This will draw about 600 vectors proportional to average linear velocity. Read more about these and other plot input settings in the User Guide.


Make a Plot of Entire Model Area with Head Contours and Vectors

Make the plot by selecting *Make Plot/All Selected Features* and then select level 1 and press *OK*. Your plot will look like this:



Make Close-up Plots of 3D Area, Both Levels

To see more clearly the area of interest, zoom in so the 3D area covers most of your plot window, something like this:




This is just the same plot, but enlarged. You can easily make a more accurate plot of this close-up window. First, change the plot window to this view by right-clicking over the plot and then selecting *Set Plot Window to Current View*. Also, under *Plot Input/Contour Settings*, change the *Increment* to 0.2 instead of 0.5:


Data: contour settings

Surface	Subtract	Points_Evaluated	Increment	Minimum	Maximum
h	no	20000	0.2		

Now make a new plot by selecting *Make Plot/All Selected Features* selecting level 1 and pressing *OK*. The plot should look like this:



If you repeat this, but make the plot of level 2, you get something like this:



The results show different head patterns, with more pronounced connection to the river in level 1 and deeper drawdown at the well in level 2 where it is screened. The anisotropy of the domains makes the drawdown ellipse-shaped, with the K1 axis oriented 30 degrees north of east. The plot of the 2nd level is

limited to the 3D area – there is no 2nd level outside the interdomain boundary that defines the limits of the 3D area. There is some drawdown near the well in level 1 due to strong downward vertical leakage between levels.

Examining Head Differences Between Levels

You can examine the difference in head between the two levels in a couple of ways. One is with the cursor information at the left. If you make a plot of heads in level 1, then move the cursor around the 3D area, you will see fairly large head differences listed at the left when you are near the well:

▲ Head - Head Below [L]:
4.505229


The positive number means the head in level 1 is greater than the head in level 2 and there is downward flow. If you move the cursor near the some parts of the river, you may see a negative head difference indicating upward flow:

▲ Head - Head Below [L]:
-0.7208703

You can also make a contour plot of the head difference between levels. Select *Plot Input/Contour Settings*, and for *Surface*, select *dh*, which makes the contour plot a plot of the difference in head between this level and the one below:

Data: contour settings					
Surface	Subtract	Points_Evaluated	Increment	Minimum	Maximum
dh	no	20000	0.2		

If you select *Make Plot/All Selected Features* and choose level 1, the resulting plot of head difference looks like this:



Over most of the 3D area, the difference in head is less than 0.2, but there are larger positive differences near the well, and larger negative differences near the northern part of the middle river reach. The heavier contour is the zero contour. At the interdomain boundary that is the limit of the 2-level area, heads are forced to be equal by the boundary condition, which is met at control points along the boundary and. Hence, the zero contour weaves close to the boundary.

Making a Plot with Pathlines

Now we will make a plot with pathlines emanating from the well. Select *Plot Input/What to Plot* and edit the table so it looks like this:

Data: what to plot

Window	Basemap	Basemap_File	Elements	Contours	Pathlines	Vectors	SVAS_polygons	AreaPathline_polygons	Calibration	Analysis_Inputs
	gray	Select	elements w/ details, control points	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				

The blank under Window makes subsequent plots cover the entire model, and we will display pathlines, but not vectors or SVAS polygons.

Select *Plot Input/Contour Settings* and edit the settings to show head contours with an increment of 0.5:

Data: contour settings

Surface	Subtract	Points_Evaluated	Increment	Minimum	Maximum
h	no	20000	0.5		

Select *Plot Input/Pathline Settings* and check that the settings are as follows (similar to what we had in the first tutorial):

Data: pathline settings

Step_size	Time_markers	Time_marker_increment	Total_time	Start_time	Freeze_transient	Capture_constrain	Capture_wells	Capture_lines
0.005	<input checked="" type="checkbox"/>	50	30000	0.0	<input type="checkbox"/>	<input type="checkbox"/>	Select	Select

Select *Plot Input/Pathlines/Well* and edit the row so it is like the following, which will start 15 pathlines 50% of the way down in level 2 just outside the well radius, and trace pathlines upstream.

Data: well pathlines


Well Label	Number	Start_level	Show
W	15	2.5	<input checked="" type="checkbox"/>
			<input type="checkbox"/>

Now, select *Plot Input/Pathlines/Line* and if there is a row of data there from the first tutorial, uncheck the Show column since we only want to see well pathlines:

Data: line pathlines

Label	Direction	Coordinates	Number	Start_level	Show
upstream of recharge	downstream	Edit	10	1.0	<input type="checkbox"/>
		Edit			<input type="checkbox"/>

Now make a plot of level 1, which will result in something like this:



If you move the cursor over the pathlines near the well, you will see that they are in level 2, and as you move the cursor upstream, the pathlines generally rise because of recharge imposed on top of the model; some pathlines that enter the well from the northeast rise into level 1 within the 3D area. The pathline east of the well migrates steeply downward in a stagnant zone east of the well (time markers are closely spaced here).

Analyzing the Solution in Detail


AnAqSim offers many ways to check and analyze the solution in detail. In this section we will explore some of them that apply to this model.

Examining Head at the Discharge-Specified Well

There are a couple ways to check the head at the well. First, you could select *Analysis/Discharge-Specified Well Heads/Write Heads to Run Log*, which would display this in the *Log* tab:

```
Heads at discharge-specified wells:
W: 94.1422
```

Another way is to move the cursor near the well in the *Plot* tab, right-click and select *Check Nearest Well Head and Discharge*, which will display a window like this:




Checking River Reach Discharge

Selecting *Analysis/River Line Boundary Discharges/Write Discharges to Run Log* writes the total discharge of all river reaches to the *Log* tab like this:

```
Discharges of river line boundaries:
lower : -268.9369
middle: -199.9016
upper: -261.5723
```

All three river reaches have negative discharges, meaning they are extracting water from the aquifer. You can see how discharge is distributed along a particular segment of a river reach by moving the cursor near a segment, right-clicking, and selecting *Check Nearest Line Boundary Condition*. The following is the resulting plot for the segment just west of the well:




This segment loses water at one end and gains water at the other end.

Making Profiles along a Line


A useful tool in AnAqSim allows you to create a variety of profiles along a line.

Profiles Showing Head, Domain Boundaries, and Pathlines


Start by digitizing a line along which you will make profiles, similar to the one shown in yellow below, which goes approximately through the well.



Then select *Analysis/Graph Conditions Along a Line* and paste the digitized coordinates into the *Coordinates* box and edit the rest of the form as follows:



When you press the *Make Plot* button, you will see a profile of heads like this:




The domain boundaries are shown in gray, and you can clearly see the 2 layer 3D region roughly where $1200 < x < 1700$. The red dot time markers are placed at the locations of each time marker arrow shown in the plan-view plot. The pathlines in this plot do several interesting things:

- Some are pulled up abruptly where they pass under a discharging river line boundary (e.g. the lowest pathline at about $x=850$).
- Some dive steeply as they pass under the recharge basin (several at about $x=1050$).
- One dives steeply east of the well in a stagnant zone (about $x=1650$).
- Some jump vertically as they cross the interdomain boundary from the single-level “all” domain to the 2-level 3D region (e.g. at about $x=1200$). The jump occurs because pathline elevations are determined based on water balance. For example, if 40% of the discharge is above the pathline on one side of the interdomain boundary, 40% of the discharge is above the pathline on the other side of the boundary. Because the base elevation changes and because the flow field is different in the two layers, pathlines jump appropriately at these boundaries.
- Some pathlines appear to terminate above or below the water table (Head, level 1). This is because pathlines are projected onto the line, and most of these terminations are considerably to the side of the profile line and the water table elevation differs from the water table elevation on the profile line.

If you want to change the axes (for example, make the x axis start at a different value), you can do that by selecting *Change Axes* in the menu at the top of the plot. Read in the User Guide about saving and copying chart data and images.

Profiles Showing Domain Discharges


If you select *Analysis/Graph Conditions Along a Line* and edit the dialog so you check *Domain discharge tangent to line* and make the plot you will get a graph like this:



This shows the domain discharge, which is specific discharge times saturated thickness, tangent to the line. The discharge increases generally from $x=0$ to the well, as added recharge and the impact of the well increase the discharge going east along the line. In level 2 where the well is screened, there is an abrupt shift in tangent discharge from positive to negative as you cross through the well. There is a similar, but muted shift in level 1 above the well. The steps you see in the level 1 profile at are the result of river discharges subtracting (about $x=850$) and adding (about $x=1400$) to the discharge. At about $x=1200$ and $x=1700$, the profile crosses the interdomain boundary at the edge of the 3D area. Here the sum of the tangent discharges in levels 1 and 2 in the 3D area roughly equal the total discharge in the matching single-level area (the normal component of discharge is matched at interdomain boundaries, components in other directions can differ).

Profiles Showing Extraction, Evaluating SVAS Accuracy

If you select *Analysis/Graph Conditions Along a Line* and edit the dialog so you check *Extraction* and make a plot, you will see something like this:



Extraction is the net distributed flow out of the domain due to vertical leakage and storage fluxes, in units of discharge/area [L/T]. In the single-layer area of domain “all”, the only distributed flux is recharge coming into the domain at a uniform rate of 0.0006; since this is into the domain, it is a negative extraction (-0.0006 in the interval $0 < x < 1200$). In the multi-level 3D area, in addition to recharge in level 1, there is vertical leakage, which is mostly downward out of level 1 and into level 2 where the well is screened. The vertical leakage is much larger magnitude than the recharge, so there is large positive extraction in level 1. There is the opposite in level 2, as the leakage from level 1 creates a significant distributed source.

That the modeled extraction closely matches the extraction from heads indicates that the SVAS are working well. At this point, save your model, which is the final model for the second tutorial.

To see how basis point spacing can affect the accuracy of SVAS, we will tweak the model to make it have inadequate basis point spacing. Select *Model Input/Area Source/Sink/Spatially-Variable, Well Basis Points*, select the one row there and then delete it:

Data: basis point spacings near wells

Well_Labels	Max_node_spacing	Points_per_circle
Select		


Then delete the SVAS polygon:

Data: spatially-variable area source/sink, by polygon

Label	Nesting_level	Condition_Top	Top_flux_or_head	Condition_Bottom	Bottom_flux_or_head	Node_spacing	Coordinates
							Edit

Now the model has sparse basis points in the 3D area, based on the domain SVAS settings.

Select *Solve* to solve this new, less accurate model. Then select *Analysis/Graph Conditions Along a Line* and make an extraction plot, which will look like this:



You can see with this profile that the comparison between modeled and heads-based extraction is poor in the 3D area. Use this tool to check if your basis point spacing is fine enough to give a good solution. See the User Guide for more details about extraction and SVAS. Don't save the model at this point, as it was only to point out how the extraction check can be used to evaluate SVAS accuracy.

Further Exploration for AnAqSim Users

This tutorial has been kept relatively simple so it could be done with AnAqSimEDU. For AnAqSim users, it is possible to expand and explore a bit more complexity. Here are some suggestions for modifying this model and adding some complexity:

Make the 3D area 4 levels

To do this, you will need to follow these steps:

- Edit the Domains table so you have two new domains that splice in between the top and bottom domains. Add two new domains (e.g. "3D 2" and "3D 3") and adjust the elevations and levels of these and the other domains in the 3D area. Don't change the names of the existing domains because that will affect other elements that refer to domain names.
- Edit the "3D limits" interdomain line boundary so it refers to the new suite of domains on the multi-level side of this boundary.
- Edit the well and place it in the domain you want it in, also edit the well pathlines so they start at the desired level
- Solve the system, make plots, and examine the solution.

Add Head-Specified and/or Discharge-Specified Multi-Domain Wells

AnAqSim allows two other types of wells that you could experiment with. Read about and add head-specified and/or discharge-specified multi-domain wells. The multi-domain well would have to be in the 3D area of the model, and could span 2 or more levels there. For multi-domain wells, the same head at the well

radius is maintained in all domains spanned and the total discharge of the well elements in the spanned domains equals the specified discharge. Explore the tools in the *Analysis* menu for examining the discharges and heads at these types of wells.

Wrap up and Next Steps

This concludes the second tutorial. If you want to see the input file that was generated by this tutorial or any of the tutorials, you can find the files in the same Documentation directory where the basemap was located:

- Program Files/Fitts Geosolutions/AnAqSim/Documentation/tutor2.anaq (64-bit AnAqSim)
- Program Files (x86)/Fitts Geosolutions/AnAqSim/Documentation/ tutor2.anaq (32-bit AnAqSim or AnAqSimEDU)

To explore transient and multi-level modeling with AnAqSim, please see the third tutorial, which edits this model to create transient simulations where the well discharge and recharge rates change with time.